

CHANGHE

Bei dou xing

Immobiliser

Bei dou xing Tung Thih Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Program function

Read security code

Replace engine ECU

Replace immobiliser ECU

Add a new keys

Re-program keys

Erase keys

Reset immobiliser

Reset engine ECU

Check key

Lock immobiliser

Splash

Immobiliser

Tung Thih Immobiliser(V)

Replace engine ECU

Replace immobiliser ECU

Add a new keys

Reset EMS

Tung Thih Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Program function

Read security code

Replace engine ECU

Replace immobiliser ECU

Add a new keys

Re-program keys

Erase keys

Reset immobiliser

Reset engine ECU

Check key

Lock immobiliser

Liana

Immobiliser

Immobiliser

Live data

Program keys

Erase keys

Tung Thih Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Program function

Read security code

Replace engine ECU

Replace immobiliser ECU

Add a new keys

Re-program keys

Erase keys

Reset immobiliser

Reset engine ECU

Check key

Lock immobiliser

Peps

Liana A6 knob PEPS

Learning new PEPS

learning Old PEPS

Key (keyless function) Learning

Key (immobiliser) Learning

SLU Learning

Reset EMS

EMS Learning