

JAC

Immobiliser

Binyue

Delphi Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Input security code

Set security code

Program function

Program new system

Replace immobiliser ECU

Replace engine ECU

Program keys

Program engine VIN

Program immobiliser VIN

Reset engine ECU

Reset immobiliser

Erase keys

Tricyclic remote

Heyue A30

MT Type

DIAS Immobiliser

CVT Type

DIAS Immobiliser

JAC J7

Delphi Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Input security code

Set security code

Program function

Program new system

Replace immobiliser ECU

Replace engine ECU

Program keys

Program engine VIN

Program immobiliser VIN

Reset engine ECU

- Reset immobiliser
- Erase keys
- Tricyclic remote
- JAC J3(Turin)
 - Delphi Immobiliser
 - ECU identification
 - Fault codes
 - Erase DTC
 - Live data
 - Set security code
 - Input security code
 - Set security code
 - Program function
 - Program new system
 - Replace immobiliser ECU
 - Replace engine ECU
 - Program keys
 - Program engine VIN
 - Program immobiliser VIN
 - Reset engine ECU
 - Reset immobiliser
 - Erase keys
 - DIAS Immobiliser
- JAC J6
 - Delphi Immobiliser
 - ECU identification
 - Fault codes
 - Erase DTC
 - Live data
 - Set security code
 - Input security code
 - Set security code
 - Program function
 - Program new system
 - Replace immobiliser ECU
 - Replace engine ECU
 - Program keys
 - Program engine VIN
 - Program immobiliser VIN
 - Reset engine ECU
 - Reset immobiliser
 - Erase keys
 - DIAS Immobiliser
- JAC J5

Delphi Immobiliser

- ECU identification
- Fault codes
- Erase DTC
- Live data
- Set security code
 - Input security code
 - Set security code
- Program function
 - Program new system
 - Replace immobiliser ECU
 - Replace engine ECU
 - Program keys
 - Program engine VIN
 - Program immobiliser VIN
 - Reset engine ECU
 - Reset immobiliser
 - Erase keys

DIAS Immobiliser

JAC J2

Delphi Immobiliser

- ECU identification
- Fault codes
- Erase DTC
- Live data
- Set security code
 - Input security code
 - Set security code
- Program function
 - Program new system
 - Replace immobiliser ECU
 - Replace engine ECU
 - Program keys
 - Program engine VIN
 - Program immobiliser VIN
 - Reset engine ECU
 - Reset immobiliser
 - Erase keys

DIAS Immobiliser

S3

DIAS Immobiliser

S5 1.5T

- Live data
- Program new system

- Add new key
- Add old key
- Erase keys
- Replace engine ECU
- Replace immobiliser ECU
- Reset immobiliser ECU
- Reset engine ECU
- Remote
 - 10 PIN
 - Type 1
 - Add remote
 - Type 2
 - Add remote
 - 16PIN
 - Hechang
 - Live data
 - Program function
 - Add keys
 - Erase keys
 - Heyue
 - Add remote
 - Tongyue
 - Add remote
 - Binyue
 - Add remote
 - Tricyclic remote
 - S3
 - Live data
 - Program function
 - Add keys
 - Erase keys
 - S5
 - Live data
 - Program function
 - Add keys
 - Erase keys
 - M5
 - Live data
 - Program function
 - Add keys
 - Erase keys
- PEPS
 - Heyue A30
 - CVT Type

PEPS

ESCL learn

Add keys