
CONTENTS

1.	How to create Autel ID?.....	2
2.	How to register the tool?.....	3
	a) Register tools in official website:.....	3
	b) Register on tool itself (Tablets only).....	4
3.	How to update device?.....	7
4.	How to renew subcription?.....	7
5.	How to feedback problems?.....	7
6.	How to get data log if it can't be uploaded from MaxiTools or Data Log menu?.....	8
	a) Can not be uploaded from MaxiTools.....	8
	b) Can not be uploaded from Data Log menu.....	8
7.	How to get started with the tool?.....	8
8.	What if there is communication failure with a specific module (other modules are communicating well)?.....	9
9.	What if there is communication failure with all modules?.....	9
10.	Got "Linking Error" message when using OBDII software.....	9
11.	How to print from the tablet to a network printer via a computer.....	10
	a) Setup a printer connection.....	10
	b) Install the MaxiSys Printer driver.....	10
	c) Print from a computer.....	10
12.	How to check vehicle and function coverage?.....	10
13.	How to delete vehicle software?.....	11

FAQ for OTOFIX Products

1. How to create Autel ID?

- Visit the website <https://pro.autel.com/>.
- Click at Create Autel ID button on the left side of the screen to create an ID.

Sign in or join Autel now.

If you already have a registered account, please sign in with your Autel ID and password. *If you are an user from <http://www.maxidas.com>, please sign in with your original account ID and password. If you are a new user, please create an Autel ID first.*

Join Autel now

Create an Autel ID

Free to register.
Get full access to:

- Software renewals
- Community forums
- Downloads
- On-demand trainings

Sign in

Autel ID
[Forgot your Autel ID?](#)

Password
[Forgot your password?](#)

Code [Try a different image](#)

Sign in

- Enter the required information in the input fields, and click the Get Verification Code button to get a verification code for email validation.

One account is all you need

An Autel ID is your user name for everything you do with Autel: Software renew services, free community membership, members-only software downloads, and complaint services.

* Asterisks (*) indicate fields required to complete this transaction.

Your privacy is important to us
[Read the Autel Customer Privacy Policy](#)

Preferred Language

Preferred Language *

Create an Autel ID.

Autel ID and Password

Enter your primary email address as your Autel ID. Please note that you will receive a verification email in the mailbox to validate your email address.

Autel ID *

Verification code *
[Get verification code](#)
Get the verification code from above Autel ID mail address

Password *

Confirm Password *

Your Name

Please enter your full name.

First Name *

Last Name *

Note: Select your preferred language.

Input your email address to the Autel ID box

Password: you could use your email password as the Autel login password of you could create a new one.

- The online system will automatically send a verification code to the registered email address.
- Check your email to get the verification code. Input the code in the Verification Code field and complete other required fields.
- Read through Autel's Terms and Conditions and click on Agree, and then click Create Autel ID at the bottom.

Send Me Email

 E-Mail

Stay up to date with Autel news, software updates, and the latest information on products and services.

Please type the characters you see in the image below.

 I have read and agree to the Autel [Terms of Use](#) and Autel [Privacy Policy](#).

2. How to register the tool?

a) Register tools in official website:

- Visit the website <https://pro.autel.com/>.
- Sign in with the Autel ID and password.


Sign in or join Autel now.

If you already have a registered account, please sign in with your Autel ID and password. If you are an user from <http://www.maxidas.com>, please sign in with your original account ID and password. If you are a new user, please create an Autel ID first.

- Go to "Product Registration" to register Autel tools.

b) Register on tool itself (Tablets only, such as for OTOFIX D1 Lite, D1, IM1, etc)


- Register notification will pop up when logging into Update.
Click register to start registration process.



- Sign in with Autel ID and password.




- Click OK when seeing "Log in succeeded message."



- The SN and registration password will be extracted automatically. Click "Register" for registration.



- Will see registration successful info and click OK to finish the whole process.



3. How to update device?

Tap Update icon, update the OS (If available) firstly, then update the System Programs and LibComms (If available), finally update vehicle software.

4. How to renew subscription?

There are four ways to renew the subscription.

- Log into "Update" and click "Renew" on top right, then select Payment methods and finish the payment.
- Go to the website <https://pro.autel.com/> and sign in with your Autel ID, then refer to payment instruction at the left-hand side and try.
- Pay dealer to buy update.
- Buy update card from dealers and then go to <https://pro.autel.com/> and sign in with your Autel ID, then go to redeem and try.

5. How to feedback problems?

When feedback the problems, the following information needs to be provided:

- The serial number of the tool, which you can see it on the back of the tool or in "Settings-About" page of the tool.
- A video of the whole process or a screenshot of the error message.
- If encounter problems when using the device to perform functions, you need to provide the vehicle make, year, VIN and engine model. Also need to upload data log

for analyzing. You can get data logging instruction from here:

https://www.youtube.com/watch?v=o4DkgD0D_34

- If the device has a system problem, such as crashing, unable to download software, etc., you need to go to MaxiTools—Log Collection—Start—Upload to upload the system log for analyzing.

6. How to get data log if it can't be uploaded from MaxiTools or Data Log menu?

a) *Can not be uploaded from MaxiTools (Take OTOFIX D1 as example)*

- Connect the device to a computer;
- Go to OTOFIX D1----ES File Explorer----sdcard----AppLog, then you will see the data file.
- Long press the file and tap the More icon on the right corner, then select Compress,
- Copy the ZIP file on computer.
- Send the file to Autel tech support via email.

b) *Can not be uploaded from Data Log menu (Take OTOFIX D1 as example)*

- Connect the device to a computer;
- Go to OTOFIX D1---- ES File Explorer----Scan----Datalogging;
- Select vehicle software, then you will see the data file;
- Long press the file icon, then copy it on the computer.
- Send the file to Autel tech support via email.

7. How to get started with the tool?

- Insert the V1 into the OBDII port, which is generally located under the vehicle dashboard.
- Long press the Lock/Power button to power up the Diagnostic Tablet. Ensure the Diagnostic Tablet has a charged battery or is connected to the DC power supply.
- Pair up the diagnostic Tablet with the V1 via Bluetooth to establish a communication link. **NOTE:** The Diagnostic Tablet and the V1 are configured to automatically synchronize with each other on first use, so there is no need to pair up.
- When the V1 is properly connected to the vehicle and Diagnostic Table, the VCI status button at the bottom bar on the screen displays a green BT icon. This indicates your Diagnostic Tablet is ready to start vehicle diagnosis.

8. What if there is communication failure with a specific module (other modules are communicating well)?

- Check if there are any problems, especially connection issues, in this module itself or not ;
- Check if there are any related issues/error codes in any other related modules or not; If yes, fix the related errors first;
- Still any errors please advise details and record a video to show your diagnostic process.

9. What if there is communication failure with all modules?

- Check if OBDII cable is fine/change another cable to try again;
- Check if OBDII function is communicating fine;
- Check if there are any issues in vehicle itself or not;
- Check if any other vehicles have the same issue or not; If all vehicles are not communicating, please try another new OBDII cable.
- If this vehicle is not communicating only, please check problems on the vehicle itself first.

10. Got “Linking Error” message when using OBDII software.

- Check if the vehicle testing is OBDII compliant or not (EOBD or JOBD is not supported) ;
- Vehicles adopted OBDII system in different regions around the world (For Reference):
 - Europe: Adopted OBDII system since 2006;
 - U.S.A: Adopted OBDII system since 1996;
 - Asia: Adopted OBDII system since 2009;
- Check if any other OBDII compliant vehicles(US vehicles, Ford, GM, Chrysler are suggested) are communicating with this scanner or not; If other vehicles are communicating fine, it is most likely that the vehicle you testing is NOT OBDII compliant;
- If it is confirmed that the vehicle is OBDII complaint but still linking error, please advise your region/country, screenshot of About information of your device, VIN of your vehicle to our tech support.

11. How to print from the tablet to a network printer via a computer.

a) Setup a printer connection

- Tap **Settings** on the OTOFIX Job Menu.
- Tap **Printing Settings** on the left column.
- Tap **Print via network** to activate the printing function, which enables the device to send files to the printer through the PC via Wi-Fi connection.
- Tap **Home** on the top-left corner to return to the OTOFIX Job Menu, or select another setting option for further system setup.

b) Install the MaxiSys Printer driver

- Download **Maxi PC Suite** from www.otofixtech.com > *Support Center* > *Downloads* > *OTOFIX Update Tools*, and install to your Windows-based PC.
- Double-click on **Setup.exe**.
- Select an installation language to launch the installation wizard.
- Follow the instructions on the screen and click on **Next** to continue.
- Click **Install** and the printer driver will be installed on to the computer.
- Click **Finish** to complete the installation.

c) Print from a computer

- Make sure the tablet is connected to the computer network via Wi-Fi or LAN before printing.
- Run the MaxiSys Printer program on the computer.
- Click Test Print to check whether the printer works properly.
- Tap the Print button on the toolbar of the tablet. A test document will be sent to the computer.

NOTE:

- If the **Auto Print** option in the MaxiSys Printer is selected, the MaxiSys printer will automatically print the received document.
- If the **Auto Print** option in the MaxiSys Printer is not selected, click the **Open PDF File** button to view files. Select the file(s) to be printed and click **Print**.

12. How to check vehicle and function coverage?

- Go to the website <https://www.otofixtech.com/vehicle-coverage/coverage2>
- Select the product and vehicle information;
- Click SEARCH and VIEW MORE;

Vehicle Coverage

Diagnostic Tools

Product Model: D1

Vehicle Make: Audi

Vehicle Model: Audi A4 2008->

Year: 2009(9)

Function/Sub-function:

SEARCH

Vehicle Model	Year	Engine	Chassis	Series	Vehicle Type	System	Sub-system	Function	Sub-function	Version	Note
Audi A4 2008->	2009(9)	/	/			Steering Assistance	/	Active test	/	Above Audi_V11.01	/
Audi A4 2008->	2009(9)	/	/			Steering Assistance	/	Adaptation	/	Above Audi_V11.01	/
Audi A4 2008->	2009(9)	/	/			Steering Assistance	/	Advanced ID	/	Above Audi_V11.01	/
Audi A4 2008->	2009(9)	/	/			Steering Assistance	/	Basic setting	/	Above Audi_V11.01	/
Audi A4 2008->	2009(9)	/	/			(ADAS)Lane Change Assistant	/	Basic setting	/	Above Audi_V11.01	/
Audi A4 2008->	2009(9)	/	/			(ADAS)Lane Change Assistant	/	Coding	/	Above Audi_V11.01	/
Audi A4 2008->	2009(9)	/	/			(ADAS)Lane Change Assistant	/	ECU information	/	Above Audi_V11.01	/

VIEW MORE

13. How to delete vehicle software?

- Go to Utilities---- ES File Explorer----Local---- SD----Scan----select car region----Vehicle----Long press vehicle file- click delete;
- Go to ES File Explorer—Local—SD—Scan—Download, then delete the vehicle file if any.
- Go to Data Manager-Apps Uninstall----Diagnosis/Service---long press the vehicle icon----click the delete icon on right top corner.

Note: above three steps must be taken to have the software deleted completely.

Cautious: Please only delete vehicle software when update for your device haven't expired!