Please learn the following steps to perform the Next Key Programming

1. Read Key

2. Read Key Password

3. Read EIS

4. Save Data

5. Save Dump EEPROM

6. Key Calculate (not included)

7. Load Key Dump

8. Write Key

Please learn the following steps to perform the EIS Programming

1. Load EIS IFR Data

2. Write EIS

3. Read Check EIS

Please learn the following steps to perform the ESL Programming

1. Load EIS IFR Data

2. Check Password and Key Hash

3. Write EIS W204, W212

4. Write ESL W204, W212

Please learn the following steps to perform the ESL V.1. writing

1. ***Read Key***

2. Read Key Password

3. Read ESL

4. Save ESL DATA

5. Write ESL

Please learn the following steps to perform the ESL V.2. writing

1. ***Load EIS IFR Data***

2. ***Write ESL***

Please learn the following steps to perform the ESL W204-W212 RENEW

1. ***Read ESL Data***

2. ***Load Dialer and Key Password***

3. ***ESL W204-W212 Erase***

Please learn the following steps to perform the Renew EIS incl. NEC IC

1. ***Read EIS***

2. *Load dialer password*

3. Safe DATA incl. Dialer Password

4. ***Load DATA incl. dialer password***

5. ***Erase EIS***

Please learn the following steps to perform the Read DATA incl. CAN Adapter

Read DATA incl. CAN Adapter

Please learn the following steps to perform the VIN write new

VIN write new

Read and Write BE Key

Please learn the following steps to perform the Keyless Go Key Programming

Keyless Go Key Programming

Sample cable W221, W216, W164

CAN Adapter incl. 120 R

Read Adapter

1. ***Key Read Adapter IR***

2. ***PCB Nec Adapter***

CAN-PIN Connector

EIS Model Old and New