## **ALLSCANNER Cloud diagnostics**

Note: Recommended using Microsoft WIN7 or more of the system. Computers are required to install the Microsoft IE11 browser or Google. Android and IOS systems are not supported for the time being.

1.Installation of ALLSCANNER device driver management"VX MANAGER";





# Here nothing to choose, directly point "NEXT" go down:

SCREEN2EXE/SCREEN2SWF Player			– 🗆 X
Recycle Bin Computer- Shortcut	6		
	Setup - VX Manager		
	Select Components Which components should be installed? Select the components you want to install; clear the components you d install. Click Next when you are ready to continue.	2 Io not want to	
	1 - PASSTHRU 2 - HONDA 3 - TOYOTA 4 - J.R 5 - SUBARU 7 - FORD 8 - PORSCHE 9 - GM 10 - VW 50 - RP1210	E V	
	Current selection requires at least 50.2 MB of disk space.		
	< Back Nrvst >	Cancel	
the second se			
			EN ? ? B



## 2.Connected to the diagnostic equipment, the computer automatically install the driver;



# 3.The driver installed after open the "VX MANAGER", select the top menu VX CLOUD";

SCREEN2EXE/SCREEN2SWF P	layer									_		×
Recycle Bin Computer - Shortcut		LLScanner	Cevice	🚍 Diagnostic	💕 J2534 App	品 R	emote	📑 VX Cloud				
$\mathbf{Y}$		Information	#		Value							
VX Manager	~		Hardw	are								
		Licenses	Serial Nu	umber	V52XP55555							
	-		Interfa	ace	USB							
	X	Configure	Nam	e	VCX-PLUS			• LT				
		₽.	Versi	on	1.1.0.0			0				
			Dat	e	2014-01-01		_					
			Softw	are				VEHICLE				
			Nam	e	VCX.BIN							
			Versi	on	1.2.2.9	5	ReConnect		SolfTact			
			Date	e	2016-07-21	4	Reconnect	*	Sell lest			
			Softw	are		_						
			Nam	e	VCXSDK	÷	Firmware		License			
			Versi	on	1.4.1.1							
			Date	e	2016-09-02		HW Test	ር	Restart			
	Versi	on: 1.2.0.0412						Network: Online	OBD Volt: 3.09 V			
							_					
									en 🕐 🛱 👺	🗎 🧄 🏘 🖬	10:54 9/13/	4 AM /2016
	00000000000000000000000000000000000000										0.59/5.2	77 17 (1)

# Point open "start cloud diagnostics" will automatically open the default browser, enter the cloud diagnostics

index

### page, enter the dealer to the account and password;



← → S http://cloud.vxdiag.net/login				□ <u>×</u> ħ ★ ¤
Cloud Diagnostic			? HELP	~
	Access to the dealer account			
	用户登录 (Sign In)			
	Password ×			
	登录 (SIGN IN)			
	注册新用户 (Register)			
	注册 (REGISTER)			
	VXDIAG 2016 Cloud Diagnostic @ VXDIAG 2016			
🛞 📜 💦 🙆		en 🍞 🛱 🧮 📋 🗊	Խ 🏍 at 🔯 y	11:15 AM 9/14/2016

### 4.Select the required models in the main interface

#### lcon;

2016/10/13

index



Select "Open Cloud diagnostics" and enter the cloud server (*Note: to enter the cloud server must be connected to the device*);



index

St. 62 6		المتراجع والأربية والمتركب والمتحد والم	_ <b>d</b> ×
+ A http://cloud.vxdiag.net/h	ome/diagnostic/MAZDA	✓ C	th the test of test o
VXDIAG		运行状态 (Running Status): Running 오	^
Diagnostic Cloud Apps			
Device		User Name:	
Device Info		Server Name:	
Account		VXDIAG RDP Server	启动云诊断 (START CLOUD)
Ser Account		Operation:	
Message Message Inbox	$\bigcirc$	Average. 5 ms. Go	
	$(\mathcal{M})$		
	$\bigcirc$		
		VXDIAG.COM Close	
			打开云诊断 (OPEN CLOUD)
		VXDIAG Cloud Diagnostic @ VXDIAG 2016	
			EN (?) 2
			9/14/2016
← → <pre>Mttp://cloud.vxdiag.net/h</pre>	ome/diagnostic/MAZDA 👂	C SVXDIAG Cloud Diagnostic ×	<b>↑</b> ★☆
VXDIAG		运行状态 (Running Status): Running Set	^
Diagnostic		<b>网络地址 (Network IpAddr):</b> 120.24.46.37	
Cloud Apps	• VCXRDP		×
		Remote Desktop Connection	
		The publisher of this remote connection cannot be identified. Do you want to connect anyway?	
User Account		This remote connection could harm your local or remote computer. Do not connect unless you know where this connection came from or have used it before.	启动云诊断 (START CLOUD)
Message		Publisher: Unknown publisher	
Message Inbox		Type: Remote Desktop Connection Remote computer: 120 24 46.37	
		☑ Don't ask me again for connections to this computer	
	C	Don't ask me again for connections to this computer Ornect Cancel	
		Don't aak me again for compections to this computer O Details Connect Cancel	
		Don't ask me again for connections to this computer Ornect Cancel	
		Don't ask me again for connections to this computer Other Connect Cancel	打开云诊断 (OPEN CLOUD)
		Don't ask me again for connections to this computer	打开云诊断 (OPEN CLOUD)
		Don't ask me again for connections to this computer Details Connect Cancel Connect Cancel	打开去诊断 (OPEN CLOUD)

index



#### 5.Open diagnostic software for vehicle diagnosis.

Mazda IDS-101.05	- H	120.24.46.37	_ 8 ×		6 X
🔶 🛥 🎸 🎓					
		Vehicle Specification			=
					<u>i</u>
Vehicle: ATENZA (JPN) / MAZDA6 (General)					
Engine Type: LF					
Capacity: 2.0L					
Transmission: Automatic					
VIN LFPH4ABC359001330					
•					
	Complete				
				- 🔮 🖡 🔉 🔞 🙀 🕪	11:17
Mazda IDS-101.05	<b>H</b>	120.24.46.37	_ 8 ×		<b>F</b> X
Mazdə IDS-101.05		120.24.46.37	- ë x		2 X
Mazda IDS-101.05	H	120.24.46.37	_ 8 X		
Mazda IDS-101.05	*	120.24.46.37	- 8 ×		
Mazda IDS-101.05		120.24.46.37	- 8 ×		
Mazda IDS-101.05	*	120.24.46.37	_ 8 ×		
Mazda IDS-101.05		120.24.46.37	- 8 ×		
Mazda IDS-101.05		120.24.46.37	- 8 ×		
Mazda IDS-101.05	*	120.24.46.37	- 8 ×		
Mazda IDS-101.05		120.24.46.37	_ ð ×		
Mazda IDS-101.05		120.24.46.37	- 8 ×		
Mazda IDS-101.05		120.24.46.37	_ 8 ×		
Mazda IDS-101.05		120.24.46.37	_ 8 ×		
Mazda IDS-101.05		120.24.46.37	- 8 ×		
Mazda IDS-101.05		120.24.46.37	- 8 ×		
Mazda IDS-101.05		120.24.46.37	_ 8 ×		
Mazda IDS-101.05		120.24.46.37	- 8 x		
Mazda IDS-101.05		120.24.46.37	- 8 x		
Mazda IDS-101.05		120.24.46.37	- 8 ×		
Mazda IDS-101.05	Air conditioning compress	120.24.46.37	- 8 x		

🔝 Mazda ID	S-101.05			+		120.24.46.37	_ 8 ×			<b>1</b>
<b>~</b>	-	1=								
DTCCM 3	NT	FUELSYS OL-Drive	IVS Off Idle	TR						
ECT	69° C	-20 15		125	10	7,5	É.	25	^	*
ECT	1.07V	5		10.5	10	7.5		2.5		
GEAR	2	4		12.5		/.5	5	2.5		
IAC #	0%	100		12.5	10	7.5	5	2.5	0	
IAT	-7° C	120		12.5	10	7.5	5	2.5	0	
LONGFT1	0%	-30 '15 35		12.5	10	7.5	5	2.5	0	
MAF	0.29g/s	-35 15 200		12.5	10	7.5	5	2.5	0	Ĺ
MAF	0.61V	0 <sup>+</sup> 15 5		12.5	10	7.5	5	2.5	0	
02S11	0.01V	0 <sup>+</sup> 15 1		12.5	10	7.5	5	2.5	0	
RPM	ORPM	0 <sup>+</sup> 15 5000		12.5	10	7.5	5	2.5	0	
		0 <sup> </sup> 15 35⊤		12.5	10	7.5	5	2.5	0	
				Engine coo	lant temperature					
	Ś							📼 🔮 🛱 🔺	10 😼 📜 🕕	